

Tread Width (Including Nosing)
19W4/19P4/19S4
19SW4/19SP4/19SS4
1-3/16" Center to Center of Bearing Bar

No. of Bearing Bars	1/8" Bearing Bar Depth	3/16" Bearing Bar Depth	Bolt Hole Spacing Dimension "A"
5	6-1/8"	6-3/16"	2-1/2"
6	7-5/16"	7-3/8"	4-1/2"
7	8-1/2"	8-9/16"	4-1/2"
8	9-11/16"	9-3/4"	7"
9	10-7/8"	10-15/16"	7"
10	12-1/16"	12-1/8"	7"